VX - USB-C & HDMI Video/Audio Extender.
Quickstart Guide

ab. Ashton Bentley.

Order of Operation

1 Connect 'Video out' to display

2 Connect Link Cat 7 Cable (Provided)
VXR - To VXT Port
VXT - To VXR Port
Both highlighted in Pink

3 Connect optional 'USB-C PWR IN' power supply if USB-C laptop charging required

4 Connect source to: HDMI 'Input 2' or USB-C 'Input 1' on VXT

5 Connect the provided 24v PSU to the VXR
Wait up to 10 seconds for the VXT to power

---

4 Table Inputs

HDMI — 4K — 🔊

USB-C — 4K — 🔊 — 100W PSU

⚠ Connection only for Tablebox TouchPanel
Damage to the units may occur if connected to VXR.
Tablebox (Optional)

3 USB-C

Service

Audio 🔊

Video 4K 📷 📽

1

RS232 CNTRL

4K

Service

5 ⚡

VXT TRANSMITTER

| TO VXR | PWR | VXR AUX 1 | INPUT 2 | INPUT 1 | INPUT 1 | USB-C PWR IN | SERVICE | ABNET |

ab.

VXR RECEIVER

| RS232 | AUDIO | AUX 1 INPUT | OUTPUT | TO VXT | SERVICE | PWR 24V DC |

ab.

---

2 Up to 35m CAT6A or CAT7 Cable