


### Connecting an USB-C Source


- ⚠ Check connection to device is located correctly and secured.
- ⚠ Check Laptop/device is outputting a signal.



### Video




### Content Sharing





In a VC call with input connected - press send content button on Touch-panel / Phone / Remote

### No Signal Detected



- ⚠ Check Laptop/device is connected & outputting a signal.

### Cable Retractor Operation




### Connecting an HDMI Source


- ⚠ Check connection to device is located correctly and secured.
- ⚠ Check Laptop/device is outputting a signal.



### Video




### Content Sharing




In a VC call with input connected - press send content button on Touch-panel / Phone / Remote

### No Signal Detected




- ⚠ Check Laptop/device is connected & outputting a signal.



### General Button states



**Button Behaviours with Axillary Inputs**




Typical Touchpanel button panel layouts




Single Cat6A/7Cable (up to 35m)


**Button Behaviours with Bring your own Device (BYOD)**




Typical Touchpanel button panel layouts



**BYOD**



**Content Sharing**



## Button Panel Layouts

### GUI - DX2 Control Buttons Settings

Control Buttons  
TX2

Button 1: USB-C Laptop  
Button 2: HDMI Laptop  
Button 3: Auxiliary 1  
Button 4: BYOD On/Off  
Button 5: Power On/Off

**2 Button (USB-C, HDMI)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	HDMI Laptop	Off	Off	Off

**3 Button (USB-C, HDMI, Aux1)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	HDMI Laptop	Auxiliary 1	Off	Off

**4 Button (USB-C, HDMI, Aux1, Aux2)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	HDMI Laptop	Auxiliary 1	Auxiliary 2	Off

**2 Button (USB-C, Aux1)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	Off	Auxiliary 1	Off	Off

**3 Button (USB-C, Aux1, Aux2)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	Off	Auxiliary 1	Auxiliary 2	Off

**2 Button (HDMI, Aux1)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
Off	HDMI Laptop	Auxiliary 1	Off	Off

**3 Button (HDMI, Aux1, Aux2)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
Off	HDMI Laptop	Auxiliary 1	Auxiliary 2	Off

**4 Button (USB-C, HDMI, Aux1, BYOD)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	HDMI Laptop	Auxiliary 1	Auxiliary 2	Off

**3 Button (USB-C, HDMI, BYOD)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	HDMI Laptop	Off	BYOD On/Off	Off

**3 Button (USB-C, Aux1, BYOD)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	Off	Auxiliary 1	BYOD On/Off	Off

**2 Button (USB-C, BYOD)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	Off	Off	BYOD On/Off	Off

**4 Button (USB-C, Aux1, Aux2, BYOD)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	Auxiliary 1	Auxiliary 2	BYOD On/Off	Off

**5 Button (USB-C, HDMI, Aux1, Aux2, BYOD)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	HDMI Laptop	Auxiliary 1	Auxiliary 2	BYOD On/Off

**5 Button (USB-C, HDMI, Aux1, Aux2, Power Off)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	HDMI Laptop	Auxiliary 1	Auxiliary 2	Power On/Off

**3 Button (USB-C, HDMI, Power Off)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	HDMI Laptop	Off	Power On/Off	Off

**4 Button (USB-C, HDMI, Aux1, Power Off)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	HDMI Laptop	Auxiliary 2	Power On/Off	Off

**5 Button (USB-C, HDMI, Aux1, BYOD, Power Off)**

GUI - DX2 Control Buttons Settings

Button 1	Button 2	Button 3	Button 4	Button 5
USB-C Laptop	HDMI Laptop	Auxiliary 1	BYOD On/Off	Power On/Off